

Thank you for using our products.

**INSTALLATION INSTRUCTIONS
 CLASS A/B SPLITTER
 (FOR SP40S AND SPB-160/SPB-80/4)**


Use this product according to this instruction manual. Please keep this instruction manual for future reference.


MODEL NUMBER:
 SP4Z-A/B

GENERAL:

The Class A/B Splitter (SP4Z-A/B) is designed to be used with Cooper Notification's SP40S SAFEPATH4 panel and the SAFEPATH4 Audio Booster (SPB-160 and SPB-80/4) panels. The SP4Z-A/B provides a means for expanding one supervised audio output zone to four Class B or two Class A zones. **The SP4Z-A/B is UL Listed under Standard 864**, Control Units for Fire Protective Signaling Systems. They are for indoor use only.

One SP4Z-A/B can be connected to the SP40S panel. It is to be mounted inside the panel enclosure onto the standoffs on the SP40S board. Two SP4Z-A/B's can be connected to the SPB-160. One SP4Z-A/B can be connected to the SPB-80/4. It is to be mounted inside the SPB-160 or SPB-80/4 panel on the Splitter Mounting Bracket (SPMB-4Z - purchased separately) mounted over the 24VDC Power Supply (SPBPS). The SP4Z-A/B has a maximum power output per zone that cannot exceed what is listed in Table 1.

NOTE: All **CAUTIONS** and **WARNINGS** are identified by the symbol . All warnings are printed in bold capital letters.

 **WARNING:** PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE USING THIS PRODUCT. FAILURE TO COMPLY WITH ANY OF THE FOLLOWING INSTRUCTIONS, CAUTIONS AND WARNINGS COULD RESULT IN IMPROPER APPLICATION, INSTALLATION AND/OR OPERATION OF THESE PRODUCTS IN AN EMERGENCY SITUATION, WHICH COULD RESULT IN PROPERTY DAMAGE AND SERIOUS INJURY OR DEATH TO YOU AND/OR OTHERS.

SPECIFICATIONS:

<i>Table 1: Specifications</i>			
Class A	Audio Output Voltage	25.0V	70.7V
	Maximum Output Power Per Zone	40.0W	40.0W
	Operating Voltage	24VDC	
	Standby/Alarm Current at 24VDC	15mA	
	Minimum Ground Fault Sensitivity	20 K Ohms	
Class B	Maximum Output Power Per Zone	40W	40W

WIRING INSTRUCTIONS:

NOTE: The terminal blocks on the SP4Z-A/B are removable. To remove a terminal block, pull the block straight up from the circuit board as shown in Figure 1. Attach wires to the desired connections, then plug the terminal block back on the board being careful to match and align the pins.




Figure 1: Removable Terminal Block

MOUNTING INSTRUCTIONS: (SP40S)

Figure 2 shows the mounting location of the SP4Z-A/B Splitter to the SP40S panel. Figure 3 shows the correct mounting procedure.




Figure 2:
Mounting Location




Figure 3:
SP4Z-A/B Mounting in SP40S Enclosure

1. Install 4 standoffs through the SP40s board to the 4 mounting studs of the SP40S enclosure.
2. Position the SP4Z-A/B PC board with the terminal blocks pointing to the top of the SP40S enclosure and align the mounting holes on the PC board with the mounting studs.
3. Screw the male end of the 4 cover standoffs through the SP4Z-A/B PC board and to the 4 standoff installed in Step 1. Tighten standoffs snug.
4. Attach wiring in accordance with the wiring section of this installation instruction.
5. Align the SP4Z-A/B cover with the holes in the cover standoffs and mount the cover using the 4 mounting screws. Tighten the screws hand tight.

MOUNTING INSTRUCTIONS: (SPB-160 and SPB-80/4)

Figure 4 shows the mounting location of the SP4Z-A/B Splitter to the Splitter Mounting Bracket (SPMB-4Z - purchased separately). Figure 5 shows the correct mounting procedure.




Figure 4:
SP4Z-A/B Mounting Location for the SPB-80/4 and SPB-160




Figure 5:
Mounting Diagram for SP4Z-A/B Splitter and SPMB-4Z Mounting Bracket

1. Mount the Splitter Mounting Bracket (SPMB-4Z) to the SPB-160 or SPB-80/4 according to installation instructions (P84252).
2. Position the SP4Z-A/B PC board with the terminal blocks pointing to the top of the Audio Booster enclosure and align the mounting holes on the PC board with the mounting studs.
3. Screw the male end of the 4 Hex M/F Spacers through the SP4Z-A/B PC board and to SPMB-4Z. Tighten standoffs snug plus ¼ turn.
4. Attach wiring in accordance with the wiring section of this installation instruction.
5. Align the SP4Z-A/B Cover with the holes in the cover spacers and mount the cover using the 4 mounting screws. Tighten the screws hand tight.
6. Repeat Steps 2 through 6 when installing second splitter in the SPB-160 Audio Booster.

NOTE: One SPMB-4Z mounting bracket can support two SP4Z-A/B splitters.

WIRING INSTRUCTIONS:

⚠ WARNING: SHUT OFF ALL POWER BEFORE STARTING THE INSTALLATION. ELECTRICAL SHOCK CAN CAUSE DEATH OR SERIOUS INJURY.

⚠ CAUTION: Do not move jumpers while the unit is powered on. Doing so may damage the Splitter.

Jumper Plugs J1 and J3 must be set for either Class A or Class B Wiring (Figures 6A and 6B).

NOTE: Factory setting is for Class B Wiring.




Figure 6A: Setup for Class A Wiring




Figure 6B: Setup for Class B Wiring

1. See Figures 6C and 6D for wiring diagram.

NOTE: Unused zones must have a Listed 10K Ohm EOLR installed to prevent an open trouble condition.

NOTE: Cannot utilize Class A and Class B wiring on single splitter.

2. See Figure 8 or the Splitter cover silkscreen for terminal block wiring designs.

CLASS A WIRING:




Figure 6C: Power Limited For Supervised Class A Wiring.

CLASS B WIRING:




Figure 6D: Power Limited For Supervised Class B Wiring.

⚠ WARNING: SHUT OFF ALL POWER BEFORE STARTING THE INSTALLATION. ELECTRICAL SHOCK CAN CAUSE DEATH OR SERIOUS INJURY.




Figure 7A:
Wiring Routes for Wiring the SP4Z-A/B to the SP40S


⚠ WARNING: SHUT OFF ALL POWER BEFORE STARTING THE INSTALLATION. ELECTRICAL SHOCK CAN CAUSE DEATH OR SERIOUS INJURY.

**SPLITTER ZONE
OUTPUTS**

Place AUD1 and AUD2
wire run at least 1/4" from
the 24VDC wire run.

Place Splitter output wire run
at least 1/4" above the top of
the splitter circuit board.

**24VDC
POWER SUPPLY**



Place 24VDC Splitter power
wire run at least 1/4" above
the top of the SPB-160
circuit board.

**SPB-160
PC BOARD**

Run the Audio Output wiring
along the right side and to the
bottom of the enclosure, then
along the bottom to the left
side of the enclosure, up the
left side and to the AUD IN
terminals of the splitter.

Figure 7B:
Wiring Routes for Wiring the SP4Z-A/B to the SPB-160 to the AUD1 and AUD2 Splitters.


⚠ WARNING: SHUT OFF ALL POWER BEFORE STARTING THE INSTALLATION. ELECTRICAL SHOCK CAN CAUSE DEATH OR SERIOUS INJURY.

**SPLITTER ZONE
OUTPUTS**

Place AUD1 and AUD2
wire run at least 1/4" from
the 24VDC wire run.

Place Splitter output wire run
at least 1/4" above the top of
the splitter circuit board.

**24VDC
POWER SUPPLY**



Place 24VDC Splitter power
wire run at least 1/4" above
the top of the SPB-80/4
circuit board.

**SPB-80/4
PC BOARD**

Run the Audio Output wiring
along the right side and to the
bottom of the enclosure, then
along the bottom to the left
side of the enclosure, up the
left side and to the AUD IN
terminals of the splitter.

Figure 7C:
Wiring Routes for Wiring the SP4Z-A/B to the SPB-80/4 to the AUD1 Splitter.

WIRING SPECIFICATIONS:

Cable Size: Accepts #12 - #18 American Wire Gauge (AWG) for single wire connection or #16 - #18 AWG for double wire connections.

OPERATING INSTRUCTIONS:




Figure 8:
SP4Z-A/B Faceplate

TROUBLESHOOTING PROCEDURES:

Figure 9 Power and trouble LED's on the SP4Z-A/B Splitter PC board.

1. Insure that the green POWER LED is "ON". If no LED's are lighted, check the 24VDC input power.
2. Verify wiring is correct.
3. Verify jumpers are correct.
4. If the yellow TROUBLE LED is "ON" an output circuit supervision trouble is indicated. Remove the SP4Z-A/B cover and observe the 8 yellow LED's as shown in Figure 9 to determine the reason for the trouble.
5. For each SHORT LED "ON", check the speaker output wiring for that zone for a short or a faulty speaker appliance.
6. For each OPEN LED "ON", check the speaker wire run for that zone for an open or that the end of line resistor is missing. With the zone wiring removed from the SP4Z-A/B, a resistance reading on the zone will indicate the 10K Ohm EOLR and the wire resistance if the circuit is correct.
7. If a zone output does not operate and the green POWER LED is "ON" while the yellow TROUBLE LED is "OFF", the SP4Z-A/B splitter has malfunctioned. Replace.





Figure 9:
LED Indicators on the SP4Z-A/B PC Board

ANY MATERIAL EXTRAPOLATED FROM THIS DOCUMENT OR FROM COOPER NOTIFICATION MANUALS OR OTHER DOCUMENTS DESCRIBING THE PRODUCT FOR USE IN PROMOTIONAL OR ADVERTISING CLAIMS, OR FOR ANY OTHER USE, INCLUDING DESCRIPTION OF THE PRODUCT'S APPLICATION, OPERATION, INSTALLATION AND TESTING IS USED AT THE SOLE RISK OF THE USER AND COOPER NOTIFICATION WILL NOT HAVE ANY LIABILITY FOR SUCH USE.

 WARNING: All Electrical installations shall be in accordance with the appropriate national electrical code – CAN/ULC S524, Canadian Electrical Code, Part 1, National Building Code of Canada. Final acceptance is subject to Authorities Having Jurisdiction.

LIMITED WARRANTY

Cooper Wheelock, Inc. dba Cooper Notification and Cooper Notification, Inc. (each, a "Seller") products must be used within their published specifications and must be PROPERLY specified, applied, installed, operated, maintained and operationally tested in accordance with these instructions at the time of installation and at least twice a year or more often and in accordance with local, state and federal codes, regulations and laws. Specification, application, installation, operation, maintenance and testing must be performed by qualified personnel for proper operation in accordance with all of the latest National Fire Protection Association (NFPA), Underwriter's Laboratories (UL), National Electrical Code (NEC), Occupational Safety and Health Administration (OSHA), local, state, county, province, district, federal and other applicable building and fire standards, guidelines, regulations laws and codes including, but not limited to, all appendices and amendments and the requirements of the local authority having jurisdiction (AHJ). Seller products when properly specified, applied, installed, operated, maintained and operationally tested as provided above are warranted against mechanical and electrical defects for a period of (a) three (3) years from date of manufacture with respect to MEDC and Seller Industrial Signals and Seller Fire and Security Notification Appliances and Devices, or (b) one (1) year from date of manufacture with respect to Waves and SafePath Voice Evacuation and Mass Notification Systems (date of manufacture is determined by date code.) Correction of defects by repair or replacement shall be at Seller's sole discretion and shall constitute fulfillment of all obligations under this warranty. THE FOREGOING LIMITED WARRANTY SHALL IMMEDIATELY TERMINATE IN THE EVENT ANY PART NOT FURNISHED BY SELLER IS INSTALLED IN THE PRODUCT. THE FOREGOING LIMITED WARRANTY SPECIFICALLY EXCLUDES ANY SOFTWARE REQUIRED FOR THE OPERATION OF OR INCLUDED IN A PRODUCT. SELLER MAKES NO REPRESENTATION OR WARRANTY OF ANY OTHER KIND, EXPRESS, IMPLIED OR STATUTORY WHETHER AS TO MECHANICAL, FITNESS FOR A PARTICULAR PURPOSE OR ANY OTHER MATTER.

USERS ARE SOLELY RESPONSIBLE FOR DETERMINING WHETHER A PRODUCT IS SUITABLE FOR THE USER'S PURPOSES, OR WHETHER IT WILL ACHIEVE THE USER'S INTENDED RESULTS. THERE IS NO WARRANTY AGAINST DAMAGE RESULTING FROM MISAPPLICATION, IMPROPER SPECIFICATION, ABUSE, ACCIDENT OR OTHER OPERATING CONDITIONS BEYOND SELLER'S CONTROL.

SELLER DOES NOT WARRANT THAT THE OPERATION OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE OR THAT THE SOFTWARE WILL MEET ANY OTHER STANDARD OF PERFORMANCE, OR THAT THE FUNCTIONS OR PERFORMANCE OF THE SOFTWARE WILL MEET THE USER'S REQUIREMENTS. SELLER SHALL NOT BE LIABLE FOR ANY DELAYS, BREAKDOWNS, INTERRUPTIONS, LOSS, DESTRUCTION, ALTERATION, OR OTHER PROBLEMS IN THE USE OF A PRODUCT ARISING OUT OF OR CAUSED BY THE SOFTWARE.

THE LIABILITY OF SELLER ARISING OUT OF THE SUPPLYING OF A PRODUCT, OR ITS USE, WHETHER ON WARRANTIES, NEGLIGENCE, OR OTHERWISE, SHALL NOT IN ANY CASE EXCEED THE COST OF CORRECTING DEFECTS AS STATED IN THE LIMITED WARRANTY AND UPON EXPIRATION OF THE WARRANTY PERIOD ALL SUCH LIABILITY SHALL TERMINATE. SELLER IS NOT LIABLE FOR LABOR COSTS INCURRED IN REMOVAL, REINSTALLATION OR REPAIR OF A PRODUCT BY ANYONE OTHER THAN SELLER OR FOR DAMAGE OF ANY TYPE WHATSOEVER, INCLUDING BUT NOT LIMITED TO, LOSS OF PROFIT OR INCIDENTAL, INDIRECT, CONSEQUENTIAL, SPECIAL, PUNITIVE OR EXEMPLARY DAMAGES. THE FOREGOING SHALL CONSTITUTE THE SOLE REMEDY OF THE PURCHASER AND THE EXCLUSIVE LIABILITY OF SELLER.

IN NO CASE WILL SELLER'S LIABILITY EXCEED THE PURCHASE PRICE PAID FOR A PRODUCT.

LIMITATION OF LIABILITY

SELLER'S LIABILITY ON ANY CLAIM OF ANY KIND, INCLUDING NEGLIGENCE AND BREACH OF WARRANTY, FOR ANY LOSS OR DAMAGE RESULTING FROM, ARISING OUT OF, OR CONNECTED WITH THIS CONTRACT, OR FROM THE MANUFACTURE, SALE, DELIVERY, RESALE, REPAIR OR USE OF ANY PRODUCT COVERED BY THIS ORDER SHALL BE LIMITED TO THE PRICE APPLICABLE TO THE PRODUCT OR PART THEREOF WHICH GIVES RISE TO THE CLAIM. SELLER'S LIABILITY ON ANY CLAIM OF ANY KIND SHALL CEASE IMMEDIATELY UPON THE INSTALLATION IN THE PRODUCT OF ANY PART NOT FURNISHED BY SELLER. IN NO EVENT SHALL SELLER BE LIABLE FOR ANY CLAIM OF ANY KIND UNLESS IT IS PROVEN THAT ITS PRODUCT WAS THE DIRECT CAUSE OF SUCH CLAIM. FURTHER, IN NO EVENT, INCLUDING IN THE CASE OF A CLAIM OF NEGLIGENCE, SHALL SELLER BE LIABLE FOR INCIDENTAL, INDIRECT, CONSEQUENTIAL, SPECIAL, PUNITIVE OR EXEMPLARY DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE PRECEDING LIMITATION MAY NOT APPLY TO ALL PURCHASERS.