

Installation Instructions Fastrail with Edge Protector

Installation and wiring should be performed by qualified personnel only - Equipment damage and/or malfunction may result from improper installation. Remove all power from the system until the installation is complete and ready for testing. All work of any kind shall be performed to meet the requirements of any and all local, state and federal codes and/or standards set by the authority having jurisdiction. SNAC unit is supplied by others.

Installation Procedure

- Install fastrail to wall using appropriate hardware.
- Install edge protectors by sliding them into each wire hole location.
- Install addressable module unit by spreading apart sides and sliding addressable module into slots.
- Connect all wiring to appropriate terminals.

