

# Installation Instruction Vandalism Detector Guard



Installation and wiring should be performed by qualified personnel only - Equipment damage and/or malfunction may result from improper installation. Remove all power from the system until the installation is complete and ready for testing. All work of any kind shall be performed to meet the requirements of any and all local, state and federal codes and/or standards set by the authority having jurisdiction.

## Installation Instruction

- 1) Temporarily mount back plate to back box.
- 2) Using the back plate as a template, drill 4 holes (5/16" dia) through back plate mounting holes into ceiling.
- 3) Insert anchors into ceiling through drilled mounting plate holes.
- 4) Install lag bolts into anchors. With back box securely fastened to ceiling, remove mounting screws from detector base to back box.
- 5) Pull wires through back plate, and mount smoke detector base to back box.
- 6) Connect wires to smoke detector base screw terminals as specified in smoke detector installation instructions.
- 7) Install smoke detector into base.
- 8) Attach guard onto mounting flange at the top of the back plate.
- 9) Install the tamper-proof screws through the side holes of the mounting flange and into the threaded inserts of the guard. Tighten screws until guard is securely in place.

