



0201-01

Fireray® 2000 Alignment Tool & Alignment Procedure

Setup

1. Connect a temporary 3 conductor cable between the Alignment Tool and the Controller:
 - Red to '+ Controller Supply'
 - Yellow to '+ Controller Test Meter'
 - Black to '- Controller Supply'
2. Position the Alignment Tool so that it is visible from the Transmitter.
3. Follow the Procedure on the back page.

Alignment Tool: Weight: 4oz.



Fireray® 2000 Beam Smoke Detector



FFE Ltd
1455 Jamike Ave Ste 200, Erlanger
KY 41018-3147 USA

t 940 271 0435
f 972 534 1526
e america@ffeuk.com
w www.ffeuk.com

Formerly known as Fire Fighting Enterprises Ltd

Specifications and wiring information are provided for information only and are believed to be accurate. FFE Ltd assumes no responsibility for their use. Data and design are subject to change without notice. Installation and wiring instructions are shipped with the products and should always be used for actual installation. For more information, contact your Sales Representative.

Document Part No: 24-0021-03

