




BBK-1 Back Box
Stock Number: 1500001
For use on:
MBA/PBA bells
SL-1224WP
SL-1224WP
SL-120
SH-120
CSH-1224
CSL-1224




BBX-1 Back Box
Stock Number: 4270024
For use on:
MBA/PBA bells
SL-1224WP
SL-1224WP
SL-120
SH-120
CSH-1224
CSL-1224




BBX-5 Back Box Weatherproof
Stock Number: 4270048 Red, 4270049 White
For use on:
SL Series strobe/horns
SH Series strobe/horns





Includes 4 ea.
#8-32 x 3/4 screws



4BX-5 Back Box
Stock Number: 4270045 Red, 4270046 White
For use on:
SR speakers
SSR speakers
SC24 strobes



4BX-3 Back Box Surface Mount
Stock Number: 4270018 Red, 4270019 White
For use on:
SS speakers
SSS speakers




Double Gang Mounting Plate White

Stock Number: 4270044

For use on:


Any device using a 4" mounting configuration



4SP-MW Mounting Plate

Stock number: 4270043

For use on SL-5




RBX-1 Trim Skirt

Stock number: 4270032 Red, 4270033 White

For use on:

- SH24C
- SL24C
- CSH24C
- CSL24C



SPC-1 Mounting Plate

Stock number: 4270038

For use on:

- SH24C
- SL24C
- CSH24C
- CSL24C

