#### Installation Instructions **Installation Instructions Installation Instructions House Instructions HVAC Control Module**



### **Ratings and Resistive Load Chart:**

Key Switch: 3A @ 24 VDC 4A @ 125 VAC 2A @ 250 VAC

## **Ordering Information:**

Part # Description ICMLEDTEST Lamp Test Module

©Space Age Electronics, Inc. 2007 EC0306 LT10458 Rev.A



Installation and wiring should be performed by competent, licensed and trained technicians. Equipment damage and/or malfunction will occur in an improper installation. All work must comply with all Local, State and Federal Codes and Standards set in place with the proper AHJ approvals.

The package does not contain a Back Box or Front plate. These units utilize one "gang" of a Device Mount box. Multiple **Infinity** devices may be installed in one Multi-gang box, please consult your drawings for proper configuration of this device with others.

Installation:

- 1. Mount the box securely to the wall.
- 2. Make conduit connections and pull wire.
- 3. Terminate the wires per your application (See Figure 1 on page 2). Make sure system is powered down!
- 4. Attach the frame to the box using the two 6x32 self tapping screws supplied.
- 5. Cover with the **Infinity** Plate using the two color matched screws supplied.
- 6. Power System up, test and verify the operation of all installed units.

Space Age Electronics, Inc. www.1sae.com **800.486.1723** voice 508.485.0966 direct 508.485.4740 fax

No Excuses, Just Solutions!



#### **Operation:**

The **Infinity** ICM-LEDTest Module provides a Lamp Test of all LEDs on all ICMHOA Control Modules wired to it. This is accomplished by passing on the Positive 24 VDC through the ICMLEDTEST Switch thru the LED's on all the modules.

When an ICMLEDTEST Module is installed, the LEDs should light when the switch is activated, regardless of the state of an ICMENGAGE Switch (if installed). If an ICMLEDTEST Module and an ICMENGAGE Key Switch Module are supplied as part of the overall **Infinity** ICM package, the ICMENGAGE Key Switch module must be wired electrically after the ICMLEDTEST Switch (see Figure 1).




Figure 1

# **Ordering Information:**

Part # Description ICMLEDTEST Lamp Test Module

Space Age Electronics, Inc. www.1sae.com 800.486.1723 voice 508.485.0966 direct 508.485.4740 fax

No Excuses, Just Solutions!

©Space Age Electronics, Inc. 2007 LT10458 RevA 2/2