

by Honeywell

#### **EVS-CE4 Installation Instructions**

The EVS-CE4 adds four audio circuits to the EVS-50W or EVS-125W. The EVS-CE4 mounts inside the EVS-50W or EVS-125W cabinet

**Note:** Installation and wiring of this device must be done in accordance with NFPA 72 and local ordinances.

# Compatibility

The EVS-CE4 is compatible with the IntelliKnight 5820XL-EVS. For more information, refer to Installation manual for 5820XL-EVS (PN LS10061-001SK-E).

# **Board Layout & Mounting**

- Remove AC power from the EVS-50W or EVS-125W control panel and disconnect the backup batteries.
- 2. Using the four supplied screws, mount the EVS-CE4 in the EVS-50W or EVS-125W cabinet as shown in Figure 1.




Figure 1: Mounting the EVS-CE4

#### **Specifications**

Standby Current: 20 mA

Alarm Current: 180 mA

# Wiring

 Connect the supplied audio expander cable harness (PN 130426) from the connector labeled *Audio Expander* on the EVS-50W or EVS-125W to the connector on the EVS-CE4. See Figure 2.




Figure 2: Audio Expander Wire Harness Connections

2. Wire speakers for Class B (Style Y) supervision as shown in Figure 3 or for Class A (Style Z) wiring as shown in

Figure 4.




Figure 3: Class B (Style Y) Speaker Configuration




Figure 4: Class A (Style Z) Speaker Configuration

3. Restore AC power and reconnect the backup batteries.



by Honeywell

12 Clintonville Road Northford, CT 06472-1610 USA 203-484-7161 Fax: 203-484-7118 www.silentknight.com

© 2013 Honeywell International Inc.