

ACCESSORIES

AXGT

Split Core Remote with Terminals, Replacement for Any Damaged or Lost Sensor



SPECIFICATIONS

Dimensions: (Inside) .52" x .52" (Outside) 2.52" x 2.00" x 1.75"
Only For Use With: RIBXJA, RIBXJF, RIBXLCJA, RIBXLCJF, RIBXLSJA, RIBXLSJF
Can replace any damaged or lost sensor
Purpose: For use with the models listed above
Origin: Made of US and non-US parts

