

FMR-1000-RCMD LCD annunciator FPA-1000 with control

www.boschsecurity.com



BOSCH
Invented for life



- ▶ LED status indicators
- ▶ 80-character LCD display
- ▶ Piezo sounder
- ▶ Navigation buttons
- ▶ Operations keys for drill, reset, silence, and acknowledge

The FMR-1000-RCMD is a four-conductor LCD annunciator with system control capability for FCP-1000 fire panels. The annunciator shows the equivalent LEDs and LCD display. The annunciator includes a piezo sounder, navigation buttons, and operation keys for drill, reset, silence, and acknowledge. The navigation functions and the acknowledge key are accessible without restriction—even when wearing fireman gloves. The keys for reset, silence or drill can be enabled and disabled by the device key lock. The key lock can be disabled to provide full access to the controls.

Functions

Display

The Remote Command Center uses an 80-character (4 lines x 20 characters) wide viewing-angle LCD display. The display includes a long-life LED backlight. The backlight is controlled by the panel, or locally turned on upon any key press and turned off after a 30 s timeout without key press. Even when AC power is lost, the LED backlight is still turned on if a user is operating the keypad.

System Normal

When no alarms or troubles exist in the system, the Power LED lights steadily, and no other LEDs are lit. The LCD display shows two banner lines, the system status line, and the date and time.

System Off-normal

If any off-normal condition exists, the panel displays the number of off-normal conditions classified in groups. Groups include fire alarm, gas alarm, supervisory, and trouble. The panel holds up to 255 events for each group at a time. Any restored event is deleted from the list.

Piezo Sounder

The Remote Command Center has a piezo sounder that provides audible indication of the system status. In case of multiple activation, the system status with highest priority is indicated.

Operation Keys

The Remote Command Center has four operation keys:

Acknowledge: The acknowledge key is accessible without restriction. During an alarm, pressing the key turns off the piezo sounder that is sounding on an annunciator.

Drill: The Drill key can be enabled and disabled by the device key lock. Drill operation is not available if any fire alarm or supervisory conditions exist. Upon drill operation, a Drill Start Report is logged into the

history and, if so programmed, the report is transmitted to the central station. All unbypassed NACs turn on and play the patterns programmed for them. When the drill operation stops, all activated NACs turn off and a Drill Stop Report is logged into the history and, if so programmed, the report is transmitted to the central station. A system reset is automatically performed by stopping the drill so that the panel and all field devices restore to their normal operation.

Reset: The Reset key can be enabled and disabled by the device key lock. When reset operation is initiated, the piezo sounders and activated or silenced outputs turn off. All alarm, supervisory, and troubles caused by activation of SLC points are cleared. Then the control panel tries to reset all points that are in off-normal status. Not all system trouble conditions are affected by reset operation. Any input points remaining off-normal are re-indicated after reset. Reset operations are logged into the history and, if so programmed, the control panel transmits a reset report to the central station.

Silence: The silence key can be enabled and disabled by the device key lock. When the silence operation is initiated, the "Silenced" LED turns on, the panel goes into a "Silenced" status, and the piezo sounders on all keypads and annunciators turn off.

Certifications and approvals

Region	Regulatory compliance/quality marks	
USA	UL	FSYE: Emergency Alarm System Accessories (ANSI/UL 2017), UOXX: Control Unit Accessories, System (ANSI/UL 864, 9th edition) FSYE, UOXX
	CSFM	see www.boschsecurity.com (the Bosch website)
	FDNY-CoA	6101

Installation/configuration notes



WARNING

This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to: www.P65Warnings.ca.gov.

Mounting Considerations

The FMR-1000-RCMD incorporates a built-in level. The keypad can be surface mounted in the supplied back box or flush mounted using a 3-gang electrical box.

Wiring Considerations

Use four conductor, 18 AWG (ISO 0.75 mm²) or larger wire to connect the FMR-1000-RCMD to the panel's Option Bus. The total length of wire connected to the Option Bus terminals must not exceed 4000 ft.

(1219 m), regardless of the wire gauge used. For detailed wire length calculations, see the *FPA-1000 Installation and Operation Guide*.

Parts included

Quantity	Component
1	Remote Command Center in back box with cover frame Enclosure lock and two keys ¹ (replacement key: D102) Tabs with different language versions for LED and key text
1	Hardware pack
1	Literature - Installation and Operation Guide

¹ Key code stamped on both lock and key

Technical specifications

Electrical

Voltage (operating)	12 VDC or 24 VDC nominal
Current at 12 VDC	
Alarm	150 mA maximum (with annunciator lit and piezo sounder on)
Stand-by	25 mA maximum (only Power LED on)
Current at 24 VDC	
Alarm	120 mA maximum (with annunciator lit and piezo sounder on)
Stand-by	30 mA maximum (only Power LED on)

Environmental

Environment	Indoor, dry
Environment Friendly	RoHS compliant
Protection Class	IP 30 per IEC 605029
Relative Humidity	Up to 95%, non-condensing
Temperature (operating)	+32°F to +120°F (0°C to +49°C)
Temperature (storage)	-4°F to +140°F (-20°C to +60°C)

Mechanical

Operating and Display Elements

LCD	4-line x 20-character display, backlit
LEDs	Six [Fire Alarm (red), Gas Alarm (blue), Power (green), Supervisory (yellow), Silenced (yellow), and Trouble (yellow)]
Keys	Acknowledge key, 4 navigation keys
Sounder	Built-in piezo sounder

Housing

Material	ABS-FR
Color	Red

Dimensions (W x H x D)	
Back box	7.40 in x 4.41 in x 1.89 in. (188 mm x 112 mm x 48 mm)
Cover frame	7.40 in x 4.41 in x 2.40 in. (188 mm x 112 mm x 61 mm)
Weight	15.2 oz. (430 g)
Wiring	
Cable Entries	3 knockouts for ½ in. diameter conduit connectors on back, bottom and top side
Connections	4 terminals

Wire Gauge	12 AWG to 18 AWG (ISO 0.75 mm ² to 4 mm ²)
Wire Type	Non-shielded, four conductor wire

All hardware/software product names used in this document are likely to be registered trademarks and must be treated accordingly.

Ordering information

FMR-1000-RCMD LCD annunciator FPA-1000 with control

LCD annunciator with system control capability for use with FPA-1000 Analog Addressable fire Panels
Order number **FMR-1000-RCMD**

Represented by:

Europe, Middle East, Africa:
Bosch Security Systems B.V.
P.O. Box 80002
5600 JB Eindhoven, The Netherlands
Phone: + 31 40 2577 284
emea.securitysystems@bosch.com
emea.boschsecurity.com

Germany:
Bosch Sicherheitssysteme GmbH
Robert-Bosch-Ring 5
85630 Grasbrunn
Germany
www.boschsecurity.com

North America:
Bosch Security Systems, Inc.
130 Perinton Parkway
Fairport, New York, 14450, USA
Phone: +1 800 289 0096
Fax: +1 585 223 9180
onlinehelp@us.bosch.com
www.boschsecurity.us

Asia-Pacific:
Robert Bosch (SEA) Pte Ltd, Security Systems
11 Bishan Street 21
Singapore 573943
Phone: +65 6571 2808
Fax: +65 6571 2699
apr.securitysystems@bosch.com
www.boschsecurity.asia